


## Output Expansion Relay Board

Part No. EP212



## **Overview**

An optional system expansion device for use withthe EP203 three zone automatic extinguisher panel.

Mounts inside the EP203 panel to provide five volt free relay contacts (reset, mode, discharged, hold and abort).

Reset relay switchesduring the panel's reset cycle.

Moderelay switcheswhen the extinguishant system's mode is changed to manual.

Discharged relay switcheswhen a released flow switch input (e.g. from the extinguishant pipework) is received to indicate the extinguishant has been

Holdrelay switcheswhen a hold input isreceived at the panel. If the panel is in 2nd stage alarm (i.e. it is in automatic mode and detection circuits are activated, or it is in either automatic/manual mode and a manual release input is operated) the extinguishant release sequence is halted.

Abortrelay switcheswhen an abort input isreceived at the paneltocancel the extinguishant release sequence.

## **Technical Specifications**

TBC. Product dimensions (mm)

70 W x 160 H x 22 D mm. Dimensions

Weight

**Properties** Single pole changeover contacts; Rated at 1A 30V DC. DO NOT use to switch Mains voltages.



T 01942 322744

E sales@c-tec.co.uk

W www.c-tec.com



































